

3. Operation



Caution: The flow transmitter contains electrostatic discharge (ESD) sensitive devices. Use standard ESD precautions when handling the flow transmitter. See Chapter 2, Installation for ESD details.

Introduction

The flowmeter has been configured and calibrated to customer specifications. Each flowmeter contains distinct operating limits and units of measurement. This chapter will show how to determine and manipulate the configuration of the flowmeter.

Start Up

Verify the wiring before applying power. Also verify the correct power connections have been made to the flow transmitter.

1. Apply Power.
2. Wait 5 minutes for the unit to warm-up and stabilize.
3. The flowmeter evaluates sensing points as out-of-range until they have warmed up to operating temperature. The flowmeter displays a system status message of "Check Heads" until all sensing points are functioning within their calibrated range. This status message should change to the normal display of "System OK" within the 5 minute warm-up period. The output signal displayed should be representative of the estimated or calculated current process media flow.
4. The unit automatically enters the flow metering mode and the display sets to normal operation.

The flowmeter outputs should now indicate the mass flow rate in the desired units of measure.

In the event that the display or the "System OK" message does not appear, or the values are out-of-range or obviously incorrect, then turn the power off and proceed to Chapter 5 - Troubleshooting.

Using the MT91 Software with Display

Display

The flowmeter contains a 4 x 20 character LCD display. Flow rate, temperature, and system status are all accessible through the display.

Menu Window

Four components make up the menu window. They are the menu level, title, selections, and prompt line. These components are illustrated in Figure 3-1. The top line displays a menu level and title. Lines two and three are used to scroll through available options. The prompt line indicates which menu commands are appropriate.




Figure 3-1. The Menu Window

The menu level is a numeric reference which identifies each window of the menu structure. The menu level in Figure 3-1 indicates that the user is three levels deep (Level 2, sublevel 1, sub-sub-level 1). This example code can be associated functionally as 2(SETUP).1(DISPLAY).1(FLOW). Occasionally, the depth of the menu makes displaying the complete menu level impractical. When this happens, the special character ">" indicates that the menu level may be deeper than the code indicates (e.g. "2.2.3.1>RLY[1] MODE").

The title gives the user a better idea of where the system is within the menu structure. Some titles are informative enough to completely describe the menu function, while other titles are ambiguous unless the parent menus are known.

Other Window Types

Another common window encountered is a non-scrolling menu. The window is similar to the menu window except that does not scroll and all choices are contained within the window. The current selection (if there is one) is also contained in the parenthesis to the left of the question mark.

Menu Control

The prompt line and available selections display key strokes for that menu level. If a key is pressed that is not valid for that menu, the screen will stay the same. The key pad layout is shown in Figure 3-2.




Figure 3-2. Keypad Layout

0-9	Enter numbers
Y	Yes to prompts
N	No to prompts; more display
-	minus sign
.	decimal point
←	backspace
P	no special use
ENTR	accepts current value
HOME	return to main menu
UP	backup one menu level

Table 3-1. Key Functions

See Table 3-1 for key pad assignments. At any time, press the HOME key to display the main menu. HOME can be used to escape from calibration routines, restart a progression into the menu structure, or quickly change from one area of the menu to another.

When N=MORE is displayed on the prompt line, more than two menu selections are available. Press N to scroll through all the selections.

When UP is displayed on the prompt line, the UP key can be used to back out of menus. The menu moves back one level each time the UP key is pressed.

To make a selection, press the numeric key associated with the desired menu selection. The selection does not have to be displayed, but it must be one of the available selections.

Every path through the menu will eventually cause control to pass from the menu structure to a routine that performs a task such as change a parameter value, initiate a test, or calibrate the system hardware. Some of these routines still provide selections that emulate the menu structure. When the system is operating outside the menu structure, there are subtle differences in the user interface. For example, the UP key may have no affect or the prompt line won't appear.

Menu Organization

The top level of the menu is shown in Figure 3-3. The menu structure is divided into four major groups, a display function, and the revision display.

- The first menu option places the units display into the **normal display** mode. When the system is in this mode, flow and/or temperature measurements are displayed. While in the normal display mode, pressing any key will cause the main menu to display.
- The **Setup** group presents the options for customizing the system inputs and outputs. Most of the settings will be made through menus in this group.
- The **diagnostics** group provides displays that help isolate problems and test the system integrity.
- The **calibration** group is used primarily by factory technicians, but there are displays that can be helpful to the customer.
- The **verify** group provides a means to view the values of important system parameters.
- Finally, the firmware **version** is available for display.




Figure 3-3 Menu Flowchart

Quick Custom Setup

In order to use the quick operation procedure, an assumption has been made that the password is enabled (this is the factory preset condition).

If mistakes in data entry are made, press the back arrow key to correct mistake.

Menu level refers to the sequence of key to press to reach a particular function from the MAIN MENU. For example, to go to menu level 2.2.1, press HOME, 2, 2, and 1.

Y/N refers to Y Save Permanently or Change Parameter or N Do Not Save Permanently or Do Not Change Parameter.

Using Main Functions

MAIN MENU	Press HOME . Returns user to MAIN MENU. In some cases, it may be necessary to press HOME more than once.
NORMAL DISPLAY	menu level 1 . To view the NORMAL DISPLAY
DelR and RefR	menu level 4.2.5 To view a sensing point's raw signal DelR and RefR. When prompted, enter the number of the sensing point to be viewed.
PASSWORD	menu level 2.5.1.2 Enable or Disable the PASSWORD
PASSWORD	menu level 2.5.1.1 Change the user PASSWORD. If the password protection is enabled, the user must enter the current password.

Selecting Units of Measurement

After reaching the menu level, select the combination of units that will produce the desired end result.

Velocity units	menu level 2.1.1.1 <i>Length</i> 1=FT, 2=M and <i>Time</i> 1=Sec, 2=Min, 3=Hrs, 4=Day
Volume units	menu level 2.1.1.2 <i>Volume</i> 1=SCF, 2=NCM, 3=NLP <i>Area</i> 1=Square Feet, 2=Square Meters <i>Area Value</i> enter the area of the duct <i>Time</i> 1=Sec, 2=Min, 3=Hrs, 4=Day
Mass units	menu level 2.1.1.3 <i>Mass</i> 1=LBM, 2=KG, 3=TON, 4=TONNE <i>Area</i> 1=Square Feet, 2=Square Meters <i>Area Value</i> enter the area of the duct <i>Time</i> 1=Sec, 2=Min, 3=Hrs, 4=Day
Temperature units	menu level 2.1.2 1=°F 2=°C 3=K 4=°R

Setting Up Analog Outputs

Sensing Point Outputs menu level **2.2.1**

Channel 1=Chan 1 2=Chan 2

After selecting a channel, the menu automatically provides new selections to assign sensing points.

Sensing Points 1=Add All Heads 2=Add Head 3=Del All Heads
4=Del Head 5=View Assigned 6=Save

An "X" will mark on the display to show which sensing points are assigned to the selected channel. To keep changes, user *must* save assignments.

Output Parameters menu level **2.2.2**

Channel 1=Chan 1 2=Chan 2

After selecting a channel, the menu automatically provides new selections to set output parameters.

*Output Signal** 1=0-5V 2=0-10V 3=4-20mA

Mode 1=Flow 2=Temp

Full Scale enter a value

Port Zero enter a value

*Set Jumpers to match. See Chapter 2.

Setting Up Relays

Relays 1 and 2 can be set as switch points or test/status parameters. If relays 1 or 2 are used for switch points, their mode must correspond to their respective analog output channels. (e.g. If relay 1 is set to be a *flow* switch point, then analog output channel 1 must be in the *flow* mode.) If relays 1 or 2 are set to flow or temperature modes, the user **MUST** set switch point and hysteresis parameters. If this is not done, a chattering noise will be heard. Relay 3 and 4 can only be set as test/status parameters.

Relay Mode menu level **2.2.3.1**

Relay 1=Rly #1 2=Rly #2 3=Rly #3 4=Rly #4

After selecting a relay, the menu automatically provides new parameters to set the mode.

1=View Mode 2=Flow 3=Temperature

4=System Status 5=Zero Test 6= Span Test.

Switch Points menu level **2.2.3.2**

Relay 1=Rly #1 2=Rly #2 3=Rly #3 4=Rly #4

After selecting a relay, the menu automatically provides new parameters to set the switch point.

1=View Sw. Pt. 2=Above 3=Below

4=Inside 5=Outside

Hysteresis menu level **2.2.3.3**

Relay 1=Rly #1 2=Rly #2 3=Rly #3 4=Rly #4

In-Depth Custom Setup Procedure

When a flowmeter leaves the factory, it is configured to the application information know at the time of order. At installation time; however, changes to the factory settings may be necessary. There are several parameters that can be modified to customize the system. This section describes how to customize the flowmeter.

Menu level refers to the sequence of key to press to reach a particular function from the MAIN MENU. For example, to go to menu level 2.2.1, press HOME, 2, 2, and 1.

Each time a system parameter is changed, the display will prompt the user to save the change. For the change to endure through power off periods or a system reset, press Y. For a temporary change, press N. When changes are not saved, the user can restore the previous settings by cycling the input power or pressing any key for more than 10 seconds to reset the system.

In most cases, the existing value of the parameter that is changing will be displayed. If no change is required, press ENTR, select it again, or press HOME.

Since the flowmeter has multiple inputs and outputs, some parameters are stored in groups. For example, the analog output parameters apply to both channels one and two. The menu level to change the analog output parameters will prompt the user to select a channel. After making changes to that channel, back out of and re-enter the menu level to make changes to the other channels. Use either the UP key or the HOME key to back out of the menu level.

Password Protection

Before customizing the flowmeter configuration, the customer must have access to the system parameters. Two levels of password protection affect access to these parameters.

Factory Level

The highest level of protection requires a factory password for access. This password prevents inadvertent changes to variables associated with the system calibration, sensing point type, and other parameters that require factory resources to properly set.

User Level

The second level of protection requires a user password for access. This password provides the customer with the ability to limit access to parameters that affect the way the system operates.

Both levels of password protection can be enabled or disabled. When the system leaves the factory, the factory level protection will be enabled and the user level will be left disabled. No password is required to enable a level of protection, but the appropriate password is required to disable protection.



Note: The user password is set to “123” when the system is shipped.

➤ **To edit the user password**

1. Go to menu level 2.5.1 (Setup➤ Password➤ Change User PW).
2. If current user password if it is enabled, enter the current password, then press ENTR.
3. Enter desired password, then press ENTR.

➤ **To enable and disable user password protection**

1. Go to menu level 2.5.2 (Setup➤ Password➤ Enable PW).
2. If user password is already enabled, enter password. Select 2=Disable to disable password.
3. If user password is not enabled, select 1=Enable to enable the password.

Selecting Units of Measure

Internally, the unit will always work in units of standard feet per second (SF/S) and degrees Fahrenheit (°F). The user can choose from several types of units for display and output scaling. Table 3-2 shows the units of measure and their abbreviations for temperature and flow.

Table 3-2. Units of Measure and Abbreviations

Temperature	Length*	Volume*	Mass	Time
Fahrenheit (°F)	feet (SF)	cubic feet (SCF)	pounds mass (LB)	seconds (S)
Celsius (°C)	meters (NM)	cubic meters (NCM)	kilograms (KG)	minutes (M)
Kelvin (K)		liters (NLP)	English ton (TON)	hours (H)
Rankine (°R)			metric tonnes (TONNE)	days (D)

*Length and Volume units are based on FCI standard conditions (70°F and 14.7 PSIA); therefore, the units are preceded with an S.

A sequence of selections is required to set a new unit of measure for flow. At each step through this process, the existing unit will be displayed, even if it's undefined, and the user will be prompted to change it. Only Y or N will be acceptable responses to the prompts. To properly set new units, complete the menu entries until the new flow unit is displayed. If the change is only temporary, don't save any settings during the process.



Note: If only some of the settings in this process are saved, the units of measure may be incorrect after a system reset or power up.

The output may not conform to the units displayed if after partially completing the selection of new units, HOME or the hardware reset are used to exit the process.

➤ To set a new unit of measure for flow rate:

1. Go to menu level 2.1.1 (Setup⇨ Display⇨ Flow). Select from the following three options: 1=Velocity, 2=Volume, or 3=Mass and then follow the corresponding procedure below.
 - ◆ *To set velocity units:*
 2. Select 1=Velocity.
 3. The program will prompt the user to change the units of length first. Select from the following units: 1=Feet or 2=Meters.
 4. The program will prompt the user to change the units of time next. Select from the following units: 1=Seconds, 2=Minutes, 3=Hours, 4=Day. The units of velocity will display, press any key to exit to menu level 2.1.1.
 - ◆ *To set volume units:*
 2. Select 2=Volume.
 3. The program will prompt the user to change the units of volume first. Select from the following units: 1=SCF - standard cubic feet, 2=NCM - normal cubic meters, or 3=NLP - normal liter per.
 4. The program will prompt the user to change the units of area. Select from the following units: 1=Square Feet or 2=Square Meters.
 5. The user will be prompted to change the value of the area. Enter a numeric value for the area.
 6. The user will be prompted to change the units of time. Select from the following units: 1=Seconds, 2=Minutes, 3=Hours, or 4=Day. The selected units of volume will display, press any key to exit to menu level 2.1.1.

- ◆ *To set mass units:*
 2. Select 3=Mass.
 3. The user will be prompted to change the units of mass first. Select from the following units: 1=LBM - pounds mass, 2=KG - kilograms, 3=TON - English ton, or 4=TONNE - metric ton.
 4. The user will be prompted to change the units of area. Select from the following units: 1=Square Feet or 2=Square Meters.
 5. The user will be prompted to change the value of area. Enter numeric value for area.
 6. The user will be prompted to change the units of time. Select from the following units: 1=Seconds, 2=Minutes, 3=Hours, 4=Day. The units of mass will display, press any key to exit to menu level 2.1.1.
- **To set a new unit of measure for temperature:**
 1. Go to menu level 2.1.2 (Setup⤵ Display⤵ Temperature).
 2. Select from the following units: 1=°F - degrees Fahrenheit, 2=°C - degrees centigrade, 3=K - Kelvin, or 4=°R - degrees Rankine.

Selecting the Normal Display Screen

There are two formats for displaying flow information. These formats are referred to as screen 1, and screen 2. Figure 3-4 shows an example of both screens.




Figure 3-4. Normal Display Screen 1 and Screen 2

Screen 1 provides numeric output for the two analog channels.

Screen 2 provides for the display of velocity at four points simultaneously. Many systems use only four points. This display is useful when comparing the instrument with a Pitot traverse, or observing the flow profile.

- **To select screen 1 or 2:**
 1. Go to menu level 2.1.3 (Setup⤵ Display⤵ Screen Setup).
 2. Select from the following options: 1=Screen 1 or 2=Screen 2.

Assigning Sensing Points to Outputs

The first step to processing a sensing point input is to assign the sensing point to an output channel. There are two channels in the flowmeter. Assign any combination of one to sixteen sensing points signals to either or both channels.

- **To assign sensing points to outputs:**
 1. Go to menu level 2.2.1 (Setup⤵ Outputs⤵ Assign Heads).
 2. Select output channel, 1=Chan 1 or 2=Chan 2.
 3. Select from the following options:
 - 1=Add All Heads - this will assign all sensing points to the selected output channel;
 - 2=Add Head - this will assign one sensing point at a time, the user can enter up to 16 different sensing points;
 - 3=Del All Heads - this is used to clear all assigned sensing points from the selected channel;
 - 4=Del Head - this is used to delete one sensing point at a time; or
 - 5=View Assigned - the user can view the current sensing points assigned to the selected channel for 2 seconds.

➤ **To calibrate the analog output boards:**

The analog output board calibration parameters are saved on the controller board. Therefore, analog output boards are not interchangeable.

Tools needed:

- DVM (4 1/2 digit minimum)
- Calibrated 250Ω resistor

1. Turn off the power to the flowmeter.
2. Set both jumpers on the analog output board to the output type selected above.
3. Connect a DVM to the appropriate connection of the analog output board. Use a precision 250ohm resistor if the output is 4 to 20mA.
4. Apply power to the flowmeter.
5. Go to menu level 2.2.2 (Setup➤ Outputs➤ Analog). Select the Channel 1. Press 1 to select output signal.
6. Select appropriate signal type. Save selection if signal type was changed.
7. Go to menu level 4.3.1 (Calibration➤ CalOutputs➤ Analog Outputs). Select Channel 1.
8. Press keys as indicated to reach 4mA for 4-20mA output signal or press ENTR (0) for 0-5Vdc output signal and 0-10Vdc output signal.



Note: The DVM may read 20-30mV for 0-10Vdc output signal or 10-15mV for 0-5Vdc output signal.

9. Press keys as indicated to reach 20mA for 4-20mA output signal or press keys as indicated to reach 5.000Vdc for 0-5Vdc output signal or press keys as indicated to reach 10.00Vdc for 0-10Vdc output signal.
10. Repeat steps 5 through 9 for Channel 2.

Setting Discrete Outputs

Four sets of relay contacts provide the user with discrete outputs. The relays can be assigned to the parameters marked in Table 3-3.

Table 3-3. Relay Assignment by Parameters

Relay #	Flow	Temperature	Calibration Test	Zero Test	Span Test	System Status
1	◆	◆	●	●	●	●
2	◆	◆	●	●	●	●
3			●	●	●	●
4			●	●	●	●

◆ **Dependent on analog outputs**

➤ **To set discrete outputs**

1. Go to menu level 2.2.3.1 (Setup➤ Outputs➤ Relays➤ Mode)
2. Select the relay to be set: 1=Rly #1, 2=Rly #2, 3=Rly #3, or 4=Rly #4.



Note: Only relays 1 and 2 can be set as switch points.

3. Select from the following options:
 - 1=View Mode - this can be used to verify current setup;
 - 2=Flow - select this if a switch point is going to be set;
 - 3=Temperature - select this if a switch point is going to be set;
 - 4=System Status - this relay is used to notify the customer when the "System OK" is no longer displayed;
 - 5=Zero Test - this is used with the Calibration Testing discussed in the next section. During the zero test phase (4mA), the Zero Test relay is closed.
 - 6=Span Test - this is used with the Calibration Testing discussed in the next section. During the full scale test phase (20mA), the Span Test relay is closed.
 During the mid range test phase (12mA), both the Zero and Span Test Relays are closed.

If assigned, the test/status relays are ready to be connected to customer equipment.

When assigned to flow or temperature, relays 1 and 2 are affiliated directly with analog output channels 1 and 2, respectively. For this reason, relay 1 can only be assigned as a flow or temperature switch point when analog output channel 1 is assigned as a flow output for flow switch or temperature output for temperature switch. The same applies to relay 2.

Switch points are not appropriate for the test/status parameters since they are already discrete signals. Relays 1 and 2 can be assigned as switch points or as test/status parameters. As switch points, when the signal level crosses into a specified range, the relay will activate. Hysteresis can be set to prevent the relay from chattering at the switch point threshold.

The user can choose from four sets of switch point ranges. These are referred to as above, below, inside, and outside. With hysteresis, the relay will deactivate at a different threshold than at which it activates. Figure 3-7 illustrates the four switch point ranges with arbitrary hysteresis assigned.




Figure 3-7. Relay Switch Points Schemes

➤ **To set the switch points and hysteresis:**

1. Go to menu level 2.2.3.2 (Setup → Outputs → Relays → Switch Points). Relays 1 or 2 must be in a flow or temperature mode. See above section.
2. Select 1=Rly #1 or 2=Rly #2. To view the current switch point settings select 1=View Sw. Pt. To set the switch point follow one of the procedures below.
 - a. Select 2=**Above** to activate the relay above a switch point value. Enter a numeric value for the upper limit of the switch point. Press ENTR to accept the value.
 - b. Select 3=**Below** to activate the relay below a switch point value. Enter a numeric value for the lower limit of the switch point. Press ENTR to accept the value.
 - c. Select 4=**Inside** to activate the relay if flow or temperature values approach the switch point from the outside going inside. Enter a numeric value for the upper limit of the switch point range. Press ENTR to accept the value. Enter a numeric value for the lower limit of the switch point range. Press ENTR to accept the value.

- d. Select 5=**Outside** to activate the relay if flow or temperature values go outside the switch point range. Enter a numeric value for the lower limit of the switch point range. Press ENTR to accept the value. Enter a numeric value for the upper limit of the switch point range. Press ENTR to accept the value.
- 4. Select 3=Hysteresis from menu level 2.2.3 Relays.
- 5. Select 1=Rly #1 or 2=Rly #2. Enter a numeric value for the desired deactivation of the switch point. The display will read "Recovers xxx", this is the deactivation point. Press ENTR to accept the value.



Note: The factory recommends that the password be enabled after making changes to the system parameters if it has been disabled.

Daily Calibration Testing

The calibration error test interrupts the normal flow metering process to test for shifts or changes in parameters that affect the calibrated accuracy of the flowmeter. This test can be manually initiated by using the keypad to make a selection from the system menu, or it can be scheduled to automatically occur periodically with a 24-hour interval.

Both channels of the analog output card are driven to set values during the test. Figure 3-8 shows the screens that will display during the calibration test sequence.




Figure 3-8. Calibration Test Display Screens

While screen A is displayed, the analog outputs are at a 4 mA or 0 Vdc level. While screen B is displayed, the analog outputs are at a 12 mA, 2.5 Vdc or 5 Vdc. While screen C is displayed, the analog outputs are at 20 mA, 5 Vdc, or 10 Vdc. Each of these screens and corresponding outputs are sustained for two minutes. Screen D will display for each sensing point that is assigned to the flowmeter. From this point until the conclusion of the test, the analog output will be fixed at 4 mA. When screen E displays, the system has completed the calibration test and the heaters have been turned back on.

➤ **To manually initiate the Calibration Test**

1. Go to menu level 3.3.1 (Diagnostics➤ Calibration Tests➤ Start Test). The sequence of screens A through E will display.
2. To view the results of the test, select 2=Display Results, from the menu level 3.3. If the system is unable to balance out one of the sensing points, the suspect head will be noted with an x as shown in screen F. If no balance problems occurred, screen F will not display. Finally, screen G displays the deviation of the stimulated signals from the expected results.

➤ **To set up the automatic Daily Calibration Test**

◆ *Set the time of day.*

1. Go to menu level 2.6 (Setup➤ Clock). Enter the hour and press ENTR.
2. Enter the minutes and press ENTR.
3. Press any key to exit.

◆ *Set the time of the test.*

1. Go to menu level 3.4 (Diagnostics➤ Schedule Tests).
2. Select 1=Calibration Drift.
3. Enter the hour and press ENTR.
4. Enter the minutes and press ENTR.
5. Enter the seconds and press ENTR.

◆ *Enable the automatic test.*

1. Go to menu level 3.4 (Diagnosiscs➤ Schedule Tests).
2. Select 2=Enable Auto Test.
3. Select 1=Enable or 2=Disable.

With the daily automatic test enabled, the calibration drift test will run the same time each day. The normal outputs will be driven to test values and the calculated results will be available for display.

Advanced Features

The remainder of this chapter contains topics that may not be applicable to every user of the flowmeter. In most cases the flowmeter will be ready for use straight out of the box. However, there may be instances where the advanced features of the flowmeter may be needed. This section discusses how to correct for bias errors due to non-ideal installations and how to communicate with the flowmeter through the serial port.

Flow Rate Correction Equation

The flow rate correction equation or corrector is used to bias the flow rate output. The correction equation contained in the flowmeter allows the user to correct for bias errors due to non-ideal installation effects. The correction equation is applied to the measured flow rate and then this corrected flow rate is used to drive the analog outputs and manipulate the relays. The flow rate shown on the display is also the corrected value. The correction equation for the flowmeter is shown below.

$$m_{new} = C_1 + (C_2 \times m_0) + (C_3 \times m_0^2) + (C_4 \times m_0^3)$$

where m_0 = Measured Flow Rate

C_i = Correction Equation Coefficients (i = 1 through 4)

Default configuration is $C_1=0$, $C_2=1$, $C_3=0$, and $C_4=0$.

m_{new} = Corrected Flow Rate

Application of the correction equation will be illustrated in the following example. Through analysis of the process flow stream it is determined that the flow rate must be multiplied by 1.056 to output the desired value. The correction equation takes the following form.

Example:

$$m_{new} = 0 + (1.056 \times m_0) + (0 \times m_0^2) + (0 \times m_0^3) = 1.056 \times m_0$$

where

$$\begin{aligned} C_1 &= 0 \\ C_2 &= 1.056 \\ C_3 &= 0 \\ C_4 &= 0 \end{aligned}$$

A more complicated situation would be where the multiplication factor varies with the flow rate. Figure 3-9 shows the variation of desired flow rate versus the measured flow rate.




Figure 3-9. Desired Flow Rate Versus Measured Flow Rate

The relationship between the measured and the desired flow rates was determined through a least squares analysis. The coefficients for the above relation are:

$$\begin{aligned} C_1 &= -7.5672 & C_2 &= 2.09253 \\ C_3 &= -0.037082 & C_4 &= 0.0003505 \end{aligned}$$

➤ **To enter the correction equation coefficients and enable it:**

1. Go to menu level 2.2.5 (Setup⇨ Outputs⇨ Corrections).
2. Press 2=Enter Correction. Enter the user password (if it enabled).
3. Enter all the desired coefficients. When complete, press 6=Verify and Save. Scroll through the displayed coefficients then save them if they are correct.
4. Press ENTR and then 1=Enable. Select 1=Enable or 2=Disable.

Offset Adjustment of Sensing Points

Using the offset adjustment allows the customer to shift the calculated flow rate up or down to agree with another reference instrument. FCI uses a balanced order polynomial equation to map the sensing point information to a curve. The general form of this equation is shown below.

$$Flow = C1(\Delta R^{-2}) + C2(\Delta R^{-1}) + C3 + C4(\Delta R) + C5(\Delta R^2)$$

Figure 3-10 illustrates the effect of adding an offset of plus 1 ohm and adding an offset of minus 1 ohm to the raw signal.




Figure 3-10. Delta-R Versus Flow Rate

➤ **To enter an offset value:**

1. Go to menu level 4.4.4 (Calibration \rightarrow Cal Flow \rightarrow Offset).
2. Select 1=Offset Values. Enter sensing point number and value of desired offset. Units are always in ohms.
3. Select 2=Enable Offset.

Applying the Filter

For applications with noisy flow profiles, the filter can be used to reduce jumps or oscillations in the output signal. The flowmeter takes samples of the flow rate periodically at each active sensing point. If the current value jumps up when the next sample is taken, applying the filter can help smooth this jump out. The rate at which a sample is taken depends on the number of active sensing points. The more sensing points that are active, the longer the intervals between samples.

The filter strength acts stronger with increasing interval time. A filter strength of 2 for a 4-point system takes twice as long to apply than a filter strength of 2 for a 2-point system. See Figure 3-11.




Figure 3-11. Effects of Filter on Flow Signal Versus Time

The filter uses the following equation to adjust the output signal.

$$V_n = V_c + \frac{(V_s - V_c)}{f}$$

V_n = New or desired value

V_c = Current Value

V_s = Sample Value

f = Filter Strength

➤ **To change the filter strength:**

1. Go to menu level 2.2.4 (Setup▸ Outputs▸ Filter).
2. Enter desired filter strength.

Serial Communications

The flowmeter has one serial port that can be configured to use one of three EIA standard interfaces: EIA-232C, EIA-422, or EIA-485. The data transfer rate can be set to either 4800, 9600, or 19200 baud. The number of bits in a character is set to eight, and no parity bit is used.

➤ **To use serial communications:**

1. Go to menu level 2.3.3 (Setup▸ Communications▸ Protocol).
2. Select 1=Pro1 or 3=Pro 3. Protocol 1 is a command and response protocol. Protocol 2 is not defined. Protocol 3 is a limited command and response protocol used to extract flow and raw signal data for up to 4 sensing points.
3. Set the data transfer rate, character bits, and parity bit on the host system.
4. To use protocol 1, refer to Table 3-4 for a list of commands and responses. These commands must be entered in capitalized letters to be recognized by the system.
5. To use protocol 3, use the single character 'F' (flow) followed by a carriage return to display 4 sets of flow values. Use the single character 'R' (resistance) to display 4 sets of sensing point resistance values.

Time Delay

The time delay function freezes the outputs for an operator specified time period.

➤ **To use time delay:**

1. Go to menu level 7.0 (Time Delay).
2. Enter the amount of time in minutes desired for the delay length.
3. The instrument will count down the time, while freezing the output. Any key can be pushed to exit the time delay. When the time has expired the instrument will continue with normal operation.

Table 3-4. Commands and Responses for Protocol 1

Command	System Response	Description
SFPnn	X.XXXXXXXXXX	Linear flow in SF/S for sensor nn
SFOPn	X.XXXXXXXXXX	Average flow of output n (see SFUNI)
STPnn	X.XXXXXXXXXX	Standard Temperature (F) of sensor nn
STOPn	X.XXXXXXXXXX	Average temp of output n (see STUNI)
SSHnn	X	Status of sensor nn. 1 - ok, 0 - not ok
SCBnn	X.XXXXXXXXXX	Bias offsets for sensor nn (Ohms)
SC1nn	X.XXXXXXXXXX	Linearization coefficient 1 for sensor nn
SC2nn	X.XXXXXXXXXX	Linearization coefficient 2 for sensor nn
SC3nn	X.XXXXXXXXXX	Linearization coefficient 3 for sensor nn
SC4nn	X.XXXXXXXXXX	Linearization coefficient 4 for sensor nn
SC5nn	X.XXXXXXXXXX	Linearization coefficient 5 for sensor nn
SI1nn	X.XXXXXXXXXX	Reference Gain cal. factor for sensor nn
SI2nn	X.XXXXXXXXXX	Reference Offset cal. factor for sensor nn
SI3nn	X.XXXXXXXXXX	Active Gain cal. factor for sensor nn
SI4nn	X.XXXXXXXXXX	Active Offset cal. factor for sensor nn
SMNnn	X??	Minimum delta-r for sensor nn
SMXnn	X??	Maximum delta-r for sensor nn
SCTnn	X.XXXXXXXXXX	Temperature compensation adjustment
SCFnn	X.XXXXXXXXXX	Correction factor to flow output
SAREA	X.XXXXXXXXXX	Area of duct
SAUNI	TTTTT???	Units of measure for area
SFUNI	TTTT??	Units of measure for flow
SFFAC	X.XXXXXXXXXX	Conversion factor SF/S to ????
SPMPn	TTTT	Mode of output n. FLOW or TEMP
SPOPn	TTTT??	Analog output type for output n
SPSPn	X.XXXXXXXXXX	Span value for output n in ??? units
SP0Pn	X.XXXXXXXXXX	Zero value for output n in ??? units
STUNI	T	Units of measure for temperature
STMPF	X.XXXXXXXXXX	Conversion multiplier for temperature
STADF	X.XXXXXXXXXX	Conversion offset for temperature
SRRnn	X.XXXXXXXXXX	Reference resistance for sensor nn
SRDnn	X.XXXXXXXXXX	Delta-R resistance for sensor nn
SCEM	XXXX	Hex code for heads which won't balance
SBCEM	X.XXXXXXXXXX	Percent (FS) deviation from balance cal test
SLCEM	X.XXXXXXXXXX	Percent (FS) deviation from Low Flow cal. test
SMCEM	X.XXXXXXXXXX	Percent (FS) deviation from Mid Flow cal test
SHCEM	X.XXXXXXXXXX	Percent (FS) deviation from High Flow cal test
?????	?	RESPONSE TO UNKNOWN COMMAND

